



Original	Substitut
 Power	 Power
 Mute	 Mute
 Audio	 Dual
 TV / STB	 Shift + TV/R
 TV / R	 TV/R
 Sleep	 Sleep
 SUB	 Subt
 TXT	 Text
 Multi	 Smart
 P / N	 Shift + 1
 Recall	 Pre Ch
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6

Original	Substitut
 7	 7
 8	 8
 9	 9
 0	 0
 PGUP	 Vol +
 PGDN	 Vol -
 SAT	 Shift + AV
 FAV +	 Ch +
 FAV -	 Ch -
 EPG	 Guide
 Fav	 Shift + Pre Ch
 Up / CH+	 Up
 Right / Vol+	 Right
 Down / CH-	 Down
 Left / Vol-	 Left
 OK	 Ok
 Menu	 Menu





Original	Substitut	Original	Substitut
Exit	Exit	Stop	Stop
Red	Red	Rec	Rec
Green	Green	<<	<<
Yellow	Yellow	>>	>>
Blue	Blue	Play / Pause	Play
Pause	Pause	> <	Shift + Pause
Zoom	Eject	<<	<<
Edit	Format	>>	>>
Info	Info		
USB	AV		
MP3	Media		
JPEG	Shift + Media		
PVR List	List		
PIP	Shift + Ok		
A - B	Back		
T.S.	Shift + 2		
Goto	Options		

