





































Original		Substitut		Original		Substitut	
	Power		Power		5		5
	-/-- TV		Guide / EPG / -/--		5 TV		Shift + 5
	TV		TV/Radio /		6		6
	DVD		Smart / List		6 TV		Shift + 6
	Open/Close		Eject / Surround		7		7
	Mute		Mute / Dimmer		7 TV		Shift + 7
	Display		Display / Media		8		8
	PP		Back / Return		8 TV		Shift + 8
	TV/AV		AV / Input / RDS		9 TV		Shift + 9
	1		1		9		9
	1 TV		Shift + 1		0 TV		Shift + 0
	2		2		0		0
	2 TV		Shift + 2		-/--		Shift + Guide / EPG / -/--
	3		3		+10		Fav / Marker / PC
	3 TV		Shift + 3		Audio		Audio / Lang I/II
	4		4		Setup		Setup / OPT /
	4 TV		Shift + 4		Menu DVD		Menu / Home





Original	Substitut	Original	Substitut
 Menu Tv	 D.Menu / Top	 Repeat A-B	 Yellow / YouTube / Repeat
 CH+	 CH+ / Page+	 Program	 Shift + TV/Radio / Program
 CH-	 CH- / Page-	 Slow	 Shift + Play /
 Vol+	 Vol+	 Search	 Red / Netflix / Search
 Vol-	 Vol-	 Zoom	 Zoom / Size
 Up	 Up	 Clear	 Exit / Cancel / Clear
 Down	 Down	 Repeat	 Green / APP / Repeat
 Left	 Left	 Angle	 Info / Angle
 Right	 Right	 Subtitle	 Subtitle / EQ
 Enter	 OK	 PAL/NTSC	 Picture / Format
 I<<	 I<< / Preset-	 ?	 Shift + Info / Angle
 >>I	 >>I / Preset+	 ◆	 Shift + Setup / OPT / Tools
 Play	 Play / Slow	 +	 Shift + Zoom /
 Pause/Step	 Pause / Step / Freeze	 [><]	 Shift + Subtitle / EQ
 << Scan	 << / Tune-	 Timer	 Sleep / Timer
 Scan >>	 >> / Tune+	 X	 Shift + Exit / Cancel / Clear
 Stop	 Stop / Hold	 [/ =]	 Shift + Text / Goto



Original	Substitut	Original	Substitut
 Repeat A-B	 Yellow / YouTube / Repeat	 Program	 Shift + TV/Radio / Program
 Slow	 Shift + Play /	 Search	 Red / Netflix / Search
 Zoom	 Zoom / Size	 Clear	 Exit / Cancel / Clear
 Repeat	 Green / APP / Repeat	 Angle	 Info / Angle
 Subtitle	 Subtitle / EQ	 Picture / Format	 Picture / Format
 ?	 Shift + Info / Angle	 ◆	 Shift + Setup / OPT / Tools
 +	 Shift + Zoom /	 [><]	 Shift + Subtitle / EQ
 Timer	 Sleep / Timer	 X	 Shift + Exit / Cancel / Clear
 [/ =]	 Shift + Text / Goto		





Original

Substitut

Original	Substitut
	[≡]  Text / Goto

Original

Substitut

Original	Substitut

