





















































Original	Substitut	Original	Substitut
	Power		Power
	Aspect		Picture / Format
	Mute		Mute / Dimmer
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	List		Smart / List
	0		0
	Repeat		Green / APP / Repeat
	Vol+		Vol+
	S		Subtitle / EQ

Original	Substitut	Original	Substitut
	CH+		CH+ / Page+
	Vol-		Vol-
	Audio		Audio / Lang I/II
	CH-		CH- / Page-
	i		Info / Angle
	Guide		Guide / EPG / -/-
	Rec		Rec / Rec Mode
	Menu		Menu / Home
	Up		Up
	Input		AV / Input / RDS
	Left		Left
	OK		OK
	Right		Right
	Back		Back / Return
	Down		Down
	Exit / DVD Setup		Exit / Cancel / Clear
	Exit / DVD Setup		Shift + Exit / Cancel / Clear





Original	Substitut
Red / Prog	Red / Netflix / Search
Red / Prog	+  Shift + Red / Netflix / Search
Green / Step	+  Shift + Green / APP / Repeat
Yellow / Goto	Yellow / YouTube / Repeat
Blue / A-B	Blue / Prime Video / Random
Index / Stop	Pause / Step / Freeze
Hold / Play/Pause	+  Shift + Stop /
Hold / Play/Pause	Stop / Hold
Reveal / <<	<< / Tune-
Size / >>	>> / Tune+
FAV / Menu	Fav / Marker / PC
FAV / Menu	+  Shift + Fav / Marker / PC
TV.RD / Angle	TV/Radio /
Mix / I<<	I<< / Preset-
S.Page / >>I	+  Shift + >>I / Preset+
S.Page / >>I	>>I / Preset+
Title	Sound / Title

Original	Substitut
Slow	Play / Slow
Text / Zoom	+  Shift + Text /
Text / Zoom	Text / Goto
Cancel /	+  Shift + Eject / Surround
Cancel /	Eject / Surround

