




| Original   | Substitut   | Original   | Substitut   |
|--|---|--|---|
|  Power          |  Power               |  Vol-               |  Vol-                    |
|  Source (Games) |  AV / Input / RDS    |  World/Internet     |  Smart / List            |
|  1              |  1                   |  PR-                |  CH- / Page-             |
|  2              |  2                   |  Menu               |  Menu / Home             |
|  3              |  3                   |  Q.Menu             |  D.Menu / Top            |
|  4              |  4                   |  Up                 |  Up                      |
|  5              |  5                   |  Left               |  Left                    |
|  6              |  6                   |  OK                 |  OK                      |
|  7              |  7                   |  Right              |  Right                   |
|  8              |  8                   |  Down               |  Down                    |
|  9             |  9                  |  Back              |  Back / Return          |
|  TV           |  TV/Radio /        |  Exit             |  Exit / Cancel / Clear |
|  0            |  0                 |  i                |  Info / Angle          |
|  Recall       |  Fav / Marker / PC |  Movie-Music-Phot |  Display / Media       |
|  Vol+         |  Vol+              |  Guide            |  Guide / EPG / -/-     |
|  Mute         |  Mute / Dimmer     |  */o              |  Picture / Format      |
|  PR+          |  CH+ / Page+       |  */o..            |  Setup / OPT /         |

| Original   | Substitut   | Original   | Substitut   |
|--|---|--|---|
|  Power          |  Power               |  Vol-               |  Vol-                    |
|  Source (Games) |  AV / Input / RDS    |  World/Internet     |  Smart / List            |
|  1              |  1                   |  PR-                |  CH- / Page-             |
|  2              |  2                   |  Menu               |  Menu / Home             |
|  3              |  3                   |  Q.Menu             |  D.Menu / Top            |
|  4             |  4                  |  Up               |  Up                    |
|  5            |  5                 |  Left             |  Left                  |
|  6            |  6                 |  OK               |  OK                    |
|  7            |  7                 |  Right            |  Right                 |
|  8            |  8                 |  Down             |  Down                  |
|  9            |  9                 |  Back             |  Back / Return         |
|  TV           |  TV/Radio /        |  Exit             |  Exit / Cancel / Clear |
|  0            |  0                 |  i                |  Info / Angle          |
|  Recall       |  Fav / Marker / PC |  Movie-Music-Phot |  Display / Media       |
|  Vol+         |  Vol+              |  Guide            |  Guide / EPG / -/-     |
|  Mute         |  Mute / Dimmer     |  */o              |  Picture / Format      |
|  PR+          |  CH+ / Page+       |  */o..            |  Setup / OPT /         |





| Original   | Substitut   | Original | Substitut |
|--|---|----------|-----------|
|  [≡]/Text |  Text / Goto                 |          |           |
|  Red      |  Red / Netflix / Search      |          |           |
|  Green    |  Green / APP / Repeat        |          |           |
|  Yellow   |  Yellow / YouTube / Repeat   |          |           |
|  Blue     |  Blue / Prime Video / Random |          |           |
|  Lang     |  Audio / Lang I/II           |          |           |
|  [≡]..    |  Subtitle / EQ               |          |           |
|  [-o-]    |  Zoom / Size                 |          |           |
|  <<       |  << / Tune-                  |          |           |
|  Pause    |  Pause / Step / Freeze       |          |           |
|  >>      |  >> / Tune+                 |          |           |
|  Rec    |  Rec / Rec Mode            |          |           |
|  Play   |  Play / Slow               |          |           |
|  Stop   |  Stop / Hold               |          |           |
|  |   |          |           |
|  |   |          |           |
|  |   |          |           |

