





























Original		Substitut		Original		Substitut	
	Power		Power		Audio		Dual
	Mute		Mute		Tv/Radio		TV/R
	1		1		CH+		Ch +
	2		2		CH-		Ch -
	3		3		Up		Up
	4		4		Down		Down
	5		5		Right		Right
	6		6		Left		Left
	7		7		OK		Ok
	8		8		Vol+		Vol +
	9		9		Vol-		Vol -
	0		0		Red		Red
	Sleep		Sleep		Green		Green
	Info		Info		Yellow		Yellow
	Zoom		Eject		Blue		Blue
	Menu		Menu		Replay		AV
	Exit		Exit		Subtitle		Subt





	Original	Substitut	Original	Substitut
	Teletext	 Text		
	Skip	 3D		
	FAV	 Pre Ch		
	Digest	 Options		
	<<	 <<		
	Play	 Play		
	Pause	 Pause		
	>>	 >>		
	Rec	 Rec		
	Stop	 Stop		
	P▲	 >>		
	P▼	 <<		
	Guide	 Guide		
	Return	 Back		

