



































Original	Substitut	Original	Substitut
 Standby	 Power	 Tv/Radio	 TV/Radio /
 Source	 AV / Input / RDS	 Display	 Display / Media
 1	 1	 Up	 Up
 2	 2	 Left	 Left
 3	 3	 OK	 OK
 4	 4	 Right	 Right
 5	 5	 Menu	 Menu / Home
 6	 6	 Down	 Down
 7	 7	 Exit	 Exit / Cancel / Clear
 8	 8	 Mute	 Mute / Dimmer
 9	 9	 Vol+	 Vol+
 FAV	 Fav / Marker / PC	 EPG	 Guide / EPG / ---
 0	 0	 CH+	 CH+ / Page+
 Recall	 Back / Return	 Vol-	 Vol-
 P.Mode	 Picture / Format	 Media	 Shift + Display / Media
 S.Mode	 Sound / Title	 Media	 Setup / OPT /
 Sleep	 Sleep / Timer	 CH-	 CH- / Page-

Original	Substitut	Original	Substitut
 Tv/Radio	 TV/Radio /	 Tv/Radio	 TV/Radio /
 Display	 Display / Media	 Tv/Radio	 TV/Radio /
 Up	 Up	 Tv/Radio	 TV/Radio /
 Left	 Left	 Tv/Radio	 TV/Radio /
 OK	 OK	 Tv/Radio	 TV/Radio /
 Right	 Right	 Tv/Radio	 TV/Radio /
 Menu	 Menu / Home	 Tv/Radio	 TV/Radio /
 Down	 Down	 Tv/Radio	 TV/Radio /
 Exit	 Exit / Cancel / Clear	 Tv/Radio	 TV/Radio /
 Mute	 Mute / Dimmer	 Tv/Radio	 TV/Radio /
 Vol+	 Vol+	 Tv/Radio	 TV/Radio /
 EPG	 Guide / EPG / ---	 Tv/Radio	 TV/Radio /
 CH+	 CH+ / Page+	 Tv/Radio	 TV/Radio /
 Vol-	 Vol-	 Tv/Radio	 TV/Radio /
 Media	 Shift + Display / Media	 Tv/Radio	 TV/Radio /
 Media	 Setup / OPT /	 Tv/Radio	 TV/Radio /
 CH-	 CH- / Page-	 Tv/Radio	 TV/Radio /





Original	Substitut	Original	Substitut
 Rec	 Rec / Rec Mode	 Red	 Red / Netflix / Search
 T.Shift	 Info / Angle	 Green	 Green / APP / Repeat
 I/II/Audio	 Audio / Lang I/II	 Yellow	 Yellow / YouTube / Repeat
 Size/Aspect	 Zoom / Size	 Blue	 Blue / Prime Video / Random
 Text	 Text / Goto		
 Reveal	 D.Menu / Top		
 Hold	 Shift + Stop /		
 Subpage	 Eject / Surround		
 Play	 Play / Slow		
 Pause	 Pause / Step / Freeze		
 Stop	 Stop / Hold		
 Index/Rec List	 Smart / List		
 Subtitle	 Subtitle / EQ		
 <<	 << / Tune-		
 >>	 >> / Tune+		
 I<<	 I<< / Preset-		
 >>I/Mix	 >>I / Preset+		

Original	Substitut
	 Red / Netflix / Search
	 Green / APP / Repeat
	 Yellow / YouTube / Repeat
	 Blue / Prime Video / Random

