









Original	Substitut	Original	Substitut
	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Back/S.Page		Back
	Text		Text
	Index/PVR List		Smart
	Rec/Reveal		Rec
	Zoom/T.Shift		Eject
	Hold/EPG		Guide
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Vol+		Vol +
	Vol-		Vol -
	I-II		Dual
	Source		AV
	Freeze		Options
	CH+		Ch +
	CH-		Ch -
	Sleep		Sleep
	Menu		Menu
	DTV/Radio		TV/R
	Exit		Exit
	Aspect		3D





	Original	Substitut
	P.Mode	 Format
	S.Mode	 Shift + Dual
	Up	 Up
	Down	 Down
	Right	 Right
	Left	 Left
	OK	 Ok
	Media	 Media
	Info/Slow	 Info
	Step/Subtitle	 Subt
	Play	 Play
	Pause	 Pause
	I<<	 I<<
	>>I	 >>I
	Stop	 Stop
	<<	 <<
	>>	 >>

	Original	Substitut
	FAV	 Pre Ch
	FAV+/Repeat	 Shift + Ch +
	FAV-/A-B	 Shift + Ch -

