

















































































































Original	Substitut	Original	Substitut
 Power	 Power	 Menu	 Menu
 Mute	 Mute	 EPG	 Guide
 1	 1	 Exit	 Exit
 2	 2	 Up / CH + / I<<	 Up
 3	 3	 Down / CH - / >>I	 Down
 4	 4	 Right / Vol +	 Right
 5	 5	 Left / Vol -	 Left
 6	 6	 OK	 Ok
 7	 7	 Up / CH + / I<<	 I<<
 8	 8	 Down / CH - / >>I	 >>I
 9	 9	 Up / CH + / I<<	 Ch +
 0	 0	 Down / CH - / >>I	 Ch -
 FAV	 Shift + Pre Ch	 Left / Vol -	 Vol -
 Recall	 Pre Ch	 Right / Vol +	 Vol +
 Game	 Media	 Red / Zoom	 Red
 Auto	 Smart	 Green / Lan/Audio	 Green
 Info	 Info	 Yellow /	 Yellow

Original	Substitut	Original	Substitut
 MUTE	 MUTE	 TV	 AUX
 MUTE	 MUTE	 DVD	 REC MODE
 1	 1	 SAT	 PLAY MODE
 2	 2	 AUX	 II
 3	 3	 GUIDE	 ■
 4	 4	 EXIT	 ●
 5	 5	 ▲	 ◀◀
 6	 6	 ▼	 ◀
 7	 7	 ▶	 ▶▶
 8	 8	 ◀	 ⚙
 9	 9	 OK	 LIST
 0	 0	 Up / CH + / I<<	 DUAL
 FAV	 Shift + Pre Ch	 Down / CH - / >>I	 SUBT
 Recall	 Pre Ch	 Up / CH + / I<<	 OPT
 Game	 Media	 Down / CH - / >>I	 PROG
 Auto	 Smart	 Up / CH + / I<<	 SEARCH
 Info	 Info	 Down / CH - / >>I	 PICTURE
		 Left / Vol -	 ECO
		 Right / Vol +	 SLEEP
		 Red / Zoom	 TV/R
		 Green / Lan/Audio	 FORMAT
		 Yellow /	 3D
			 TIMER
			 E-MANUAL
			 REPEAT
			 ZOOM
			 TEXT
			 AV
			 TOP MENU
			 INFO
			 CLEAR
			 EXIT
			 RETURN
			 BACK
			 HOME
			 SMART
			 APP
			 MEDIA
			 + VOL
			 CH +
			 - VOL
			 CH -
			 1
			 2
			 3
			 4
			 5
			 6
			 7
			 8
			 9
			 GUIDE
			 0
			 PRE-CH
			 A
			 B
			 C
			 D
			 Mandis SHOP
			 www.mandis.tv





Original	Substitut	Original	Substitut
Blue / Text	Blue		
Red / Zoom	Eject		
Green / Lan/Audio	Dual		
Yellow /	Play		
Yellow /	Pause		
Blue / Text	Text		
<< / Tv/Radio	<<		
<< / Tv/Radio	TV/R		
>> / Subtitle	>>		
>> / Subtitle	Subt		

