































Original	Substitut	Original	Substitut
	Power		Power
	Mute		Mute / Dimmer
	Vol+		Vol+
	Vol-		Vol-
	CH+		CH+ / Page+
	CH-		CH- / Page-
	Back		Back / Return
	Smart		Smart / List
	Up		Up
	Down		Down
	Left		Left
	Right		Right
	OK		OK
	3D		3




















	Original	Substitut
	Power	Power
	OK	OK
	Up	Up
	Down	Down
	Right	Right
	Left	Left
	Back	Back / Return
	Vol +	Vol+
	Vol -	Vol-
	Home / Smart	Menu / Home
	3D	+ Shift + 3
	Mute	Mute / Dimmer
	P +	CH+ / Page+
	P -	CH- / Page-
	Ratio	Picture / Format
	List	Smart / List
	Q.Menu	D.Menu / Top














	Original	Substitut
	Subtitle	Subtitle / EQ
	Settings	Setup / OPT /
	>>	>>I / Preset+
	>>	>> / Tune+
	Play	Play / Slow
	AD / PIP	Sound / Title
	<<	I<< / Preset-
	<<	<< / Tune-
	Rec	Rec / Rec Mode
	Pause	Pause / Step / Freeze
	Text	Text / Goto
	FAV	Fav / Marker / PC
	Exit	Exit / Cancel / Clear
	Input	AV / Input / RDS
	Blue	Blue / Prime Video / Random
	Yellow	Yellow / YouTube / Repeat
	Stop / Live TV	Stop / Hold



Menu



Original	Substitut	
AV Mode	 + 	Shift + AV / Input / RDS
Green		Green / APP / Repeat
Red		Red / Netflix / Search
0		0
AD		Audio / Lang I/II
TV / PC	 + 	Shift + Fav / Marker / PC
Search	 + 	Shift + Red / Netflix /
App	 + 	Shift + Green / APP /
TV / Radio		TV/Radio /
Guide		Guide / EPG / -/--
Info		Info / Angle
Recent		Sleep / Timer
9		9
8		8
7		7
Live Menu		Display / Media
6		6

Original	Substitut	
5		5
Q.View	 + 	Shift + Display / Media
4		4
Live Zoom		Zoom / Size
3		3
2		2
1		1
T.Opt	 + 	Shift + Setup / OPT / Tools
Energy Saving		Eject / Surround
My APPS	 + 	Shift + Smart / List

