







































































| Original | | Substitut | | Original | | Substitut | |
|---|--------------|---|-------------------|---|-------------------|---|-----------------------|
|  | Power |  | Power |  | Return |  | Back / Return |
|  | Open / Close |  | Eject / Surround |  | << / Multi Speed- |  | << / Tune- |
|  | Angle |  | Info / Angle |  | Play |  | Play / Slow |
|  | Audio |  | Audio / Lang I/II |  | >> / Multi |  | >> / Tune+ |
|  | Subtitle |  | Subtitle / EQ |  | I< |  | I<< / Preset- |
|  | On/Off |  | Text / Goto |  | Pause |  | Pause / Step / Freeze |
|  | Digest |  | Smart / List |  | Stop |  | Stop / Hold |
|  | Set Up |  | Setup / OPT / |  | > |  | >> / Preset+ |
|  | Zoom |  | Zoom / Size |  | 1 |  | 1 |
|  | Title |  | Sound / Title |  | 2 |  | 2 |
|  | Up |  | Up |  | 3 |  | 3 |
|  | Menu |  | Menu / Home |  | Clear |  | Exit / Cancel / Clear |
|  | Left |  | Left |  | 4 |  | 4 |
|  | Enter |  | OK |  | 5 |  | 5 |
|  | Right |  | Right |  | 6 |  | 6 |
|  | Display |  | Display / Media |  | 0 |  | 0 |
|  | Down |  | Down |  | 7 |  | 7 |





| Original | | Substitut | |
|----------|------------|-----------|--------------------------|
| | 8 | | 8 |
| | 9 | | 9 |
| | Enter | | Fav / Marker / PC |
| | Repeat | | Green / APP / Repeat |
| | V.Surround | + | Shift + Eject / Surround |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | | Substitut | |
|----------|--|-----------|--|
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

