




Original	Substitut
 Power	 Power
 Auto	 Options
 Screen Adj.	 Format
 Menu	 Menu
 Return	 Back
 Up	 Up
 Down	 Down
 Right	 Right
 Vol+	 Vol +
 Left	 Left
 Vol-	 Vol -
 Enter	 Ok
 Default	 Exit
 Function	 Info
 Memory Viewer	 D. Menu
 Miracast	 List
 Panasonic APP	 Media

Original	Substitut
 Computer 1	 Red
 Computer 2	 Green
 Video	 AV
 HDMI 1	 Yellow
 HDMI 2	 Blue
 Digital Link	 Smart
 Mute/1	 Mute
 Mute/1	 1
 D.Zoom+/2	 2
 D.Zoom+/2	 Ch +
 Freeze/3	 Pause
 Freeze/3	 3
 AV Mute/4	 Shift + Mute
 AV Mute/4	 4
 D.Zoom-/5	 5
 D.Zoom-/5	 Ch -
 P-Timer/6	 6



