



Original	Substitut
 Power	 Power
 Tuner	 4
 Tape 1 / 2	 5
 Aux	 6
 CD 1	 1
 CD 2	 2
 CD 3	 3
 DSC	 7
 VAC	 8
 Vol -	 Vol -
 Vol +	 Vol +
 I< / Title -	 I<<
 >I / Title +	 >>I
 Stop	 Stop
 Play / Pause	 Play
 Play / Pause	 Pause
 << / Album -	 <<

Original	Substitut
 >> / Album +	 >>
 Repeat	 Text
 Program	 Shift + Sleep
 Shuffle	 Smart
 Display	 Info
 Rec	 Rec
 CLK / Timer	 Shift + AV
 Timer On / Off	 AV
 DBB	 Ch -
 DIM	 Media
 Sleep	 Sleep
 Mute	 Mute
 IS	 Dual
 MAX	 Ch +

