













| Original | Substitut | Original | Substitut |
|---|----------------|---|-----------|
|  | Power |  | Power |
|  | [i+]/Info |  | Info |
|  | [+]/Search |  | TV/R |
|  | [..≡]/Title |  | Options |
|  | DVD Menu |  | D. Menu |
|  | [*]/Mark |  | Media |
|  | [--]/A-B |  | Dual |
|  | [+]/Zoom |  | Eject |
|  | [?]/Clear |  | Exit |
|  | <<Fast |  | << |
|  | >>Fast |  | >> |
|  | <<Skip |  | I<< |
|  | >>Skip |  | >>I |
|  | Stop/Eject |  | Stop |
|  | Pause/Play |  | Play |
|  | Menu |  | Menu |
|  | Enter |  | Ok |
|  | Vol+ |  | Vol + |
|  | Vol- |  | Vol - |
|  | Mute |  | Mute |
|  | PR+ |  | Ch + |
|  | PR- |  | Ch - |
|  | Up |  | Up |
|  | Down |  | Down |
|  | Right |  | Right |
|  | Left |  | Left |
|  | Red/Audio I-II |  | Red |
|  | Green/Repeat |  | Green |
|  | Yellow/Angle |  | Yellow |
|  | Blue/Sub |  | Blue |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |





| Original | Substitut | Original | Substitut |
|----------|-----------|----------------|-----------|
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 0 | 0 | 0 | 0 |
| AV | AV | TIMER AV | AV |
| 16:9 | 16:9 | PICTURE FORMAT | Format |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

