



















Original	Substitut	Original	Substitut
	Power		Power
	Repeat		Text
	Program	+	Shift + Sleep
	Shuffle		Guide
	Tape A/R		Pre Ch
	Display		Info
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	Title >		>>
	I< Title		I<<
	Stop		Stop
	Play/Pause		Play
	Album >>		>>
	<< Album		<<
	Clock		Smart
	Timer On/Off		TV/R
	Timer		AV
	Natural		Back
	Rec		Rec
	DIM		Media
	Sleep		Sleep
	Snooze		Exit
	Bass+		Right
	Bass-		Left
	Treble+		Ch +
	Treble-		Ch -
	Inc Surr.		Menu





Original		Substitut	
	Power		Power
	Repeat		Text
	Program		Sleep
	Tape A/R		Pre Ch
	Display		Info
	Vol+		Vol +
	Vol-		Vol -
	Title >I		>>I
	I< Title		I<<
	Stop		Stop
	Play/Pause		Play
	Album >>		>>
	<< Album		<<

Original		Substitut	





Original	Substitut	Original	Substitut
	Power		Power
	Program		Sleep
	Tape A/R		Pre Ch
	Display		Info
	Vol+		Vol +
	Vol-		Vol -
	Title >I		>>I
	I< Title		I<<
	Stop		Stop
	Play/Pause		Play
	Album >>		>>
	<< Album		<<

Original	Substitut





Original	Substitut	Original	Substitut
 Power	 Power		
 Repeat	 Text		
 Program	 Sleep		
 Shuffle	 Guide		
 Tape A/R	 Pre Ch		
 Display	 Info		
 Vol+	 Vol +		
 Vol-	 Vol -		
 Title >	 >>		
 < Title	 <<		
 Stop	 Stop		
 Play/Pause	 Play		
 Album >>	 >>		
 << Album	 <<		

Original	Substitut

