



































| Original | Substitut | Original | Substitut |
|-------------|---------------------------------------------------------------------------------------------------------|------------|------------------------------------------------------------------------------------------------------------|
| On/Off |  Power | Off/Tim |  Setup / OPT / |
| Mute |  Mute / Dimmer | Text |  Text / Goto |
| Reveal |  Play / Slow | TV/AV |  AV / Input / RDS |
| Update |  Pause / Step / Freeze | Menu |  Menu / Home |
| Txt Stop |  Stop / Hold | Menu Up |  Up |
| Tune- |  << / Tune- | Info |  Info / Angle |
| Tone+ |  >> / Tune+ | Menu Left |  Left |
| Game Coo |  I<< / Preset- | OK Enter |  OK |
| Aft/Caf |  Sound / Title | Menu Right |  Right |
| Menu audio |  Audio / Lang I/II | Menu Off |  Exit / Cancel / Clear |
| Subt.List |  Subtitle / EQ | Menu Down |  Down |
| Store |  Eject / Surround | Back |  Back / Return |
| Browse |  Picture / Format | Volume+ |  Vol+ |
| Txt Expand |  Zoom / Size | Display |  Smart / List |
| Sleep Timer |  Sleep / Timer | Chan.Up |  CH+ / Page+ |
| Return TV |  TV/Radio / | Volume- |  Vol- |
| Menu video |  D.Menu / Top | Disp |  Display / Media |



