







































































































| Original | Substitut | Original | Substitut |
|---|--|---|--|
|  On/Standby |  Power |  Sleep |  Sleep |
|  1 |  1 |  Bass/Treble |  Dual |
|  2 |  2 |  X-Bass |  Subt |
|  3 |  3 |  Random |  Media |
|  4 |  4 |  I<<<</Tuning |  I<< |
|  5 |  5 |  >>>>/Tuning |  >>I |
|  6 |  6 |  Preset Up |  Up |
|  7 |  7 |  Preset Down |  Down |
|  8 |  8 |  Enter |  Ok |
|  9 |  9 |  Vol+ |  Vol + |
|  0 |  0 |  Vol- |  Vol - |
|  10+ |  Guide |  Mute |  Mute |
|  Repeat |  Text |  Folder |  Smart |
|  Open/Close |  Eject |  Demo/Dimmer |  3D |
|  Memory |  Back |  CD |  Yellow |
|  Clear |  Exit |  USB |  Blue |
|  Clock/Timer |  Shift + AV |  Tuner/Dab |  Green |

| Original | Substitut | Original | Substitut |
|--|--|---|--|
|  Sleep |  Sleep |  Bass/Treble |  Dual |
|  X-Bass |  Subt |  Random |  Media |
|  I<<<</Tuning |  I<< |  >>>>/Tuning |  >>I |
|  Preset Up |  Up |  Preset Down |  Down |
|  Enter |  Ok |  Vol+ |  Vol + |
|  Vol- |  Vol - |  Mute |  Mute |
|  Folder |  Smart |  Demo/Dimmer |  3D |
|  CD |  Yellow |  USB |  Blue |
|  Tuner/Dab |  Green | | |



