




















































































Original	Substitut	Original	Substitut
 TV Power	 Power	 <--	 Shift + Left
 Net	 Options	 Pause	 Pause
 i+	 Info	 -->	 Shift + Right
 P.Info	 Shift + Info	 1	 1
 ATV	 Smart	 2	 2
 DTV	 TV/R	 3	 3
 SAT	 Shift + Smart	 4	 4
 Radio	 Shift + TV/R	 5	 5
 Source Power	 Shift + Power	 6	 6
 <<	 <<	 7	 7
 Play	 Play	 8	 8
 >>	 >>	 9	 9
 Rec	 Rec	 0	 0
 Rec Stop	 Shift + Rec	 Recall	 Pre Ch
 Stop	 Stop	 Source	 AV
 Control	 Media	 Audio I/II/I+II	 Dual
 Ready / Time Shift	 Shift + Sleep	 Aspect	 Format





	Original	Substitut		Original	Substitut
	APP	 + 	Shift + Media		 Back
	ECO	 + 	Shift + 3D		 Subt
	Mute		Mute		 D. Menu
	Vol +		Vol +		 Sleep
	Vol -		Vol -		 +  Shift + Pause
	P +		Ch +		 Red
	P -		Ch -		 Green
	Text		Text		 Yellow
	3D		3D		 Blue
	Menu		Menu		
	EPG		Guide		
	Up		Up		
	Down		Down		
	Right		Right		
	Left		Left		
	OK		Ok		
	End		Exit		

