



































































































	Original	Substitut		Original	Substitut
		Power		Power	
		Mute		Mute	
		Info		Info	
		Angle		Back	
		Copy		Sleep	
		Zoom		Eject	
		Tv Sys		TV/R	
		Music		Shift + Menu	
		Setup		Options	
		Menu		Menu	
		1		1	
		2		2	
		3		3	
		4		4	
		5		5	
		6		6	
		7		7	
		8		8	
		9		9	
		0		0	
		Time Shift		Guide	
		Goto		Pre Ch	
		Rec		Rec	
		Stop		Stop	
		<</FR		<<	
		>>/FF		>>	
		Play/Pause		Play	
		>>I/Next		>>I	
		Subtitle		Subt	
		Audio		Dual	
		I<</Prev		I<<	
		A-B		Shift + Play	
		Repeat		Text	
		Vol+		Vol +	





Original	Substitut	Original	Substitut
 Vol-	 Vol -		
 Home	 Smart		
 X/Return	 Exit		
 Up	 Up		
 Down	 Down		
 Right	 Right		
 Left	 Left		
 Enter	 Ok		
 Wuaki TV	 AV		
 Select	 List		
 Red	 Red		
 Grenn/EPG	 Green		
 Yellow/TTX	 Yellow		
 Blue	 Blue		

