












































Original	Substitut	Original	Substitut
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Tv/AV		AV / Input / RDS
	←PR		Back / Return
	Up		Up
	Down		Down
	Left		Left
	Right		Right
	OK		OK
	Exit		Exit / Cancel / Clear
	Menu		Menu / Home
	EPG		Guide / EPG / -/--
	Mute		Mute / Dimmer
	FAV		Fav / Marker / PC
	Red		Red / Netflix / Search
	Audio		Audio / Lang I/II
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Text		Text / Goto
	Blue		Blue / Prime Video / Random
	Audio L/R		Setup / OPT /

