





































Original	Substitut
	 Mute / Dimmer
	 Power
	 Zoom / Size
	 AV / Input / RDS
	 Sound / Title
	 D.Menu / Top
	 Display / Media
	 Smart / List
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8
	 9

Original	Substitut
	 Info / Angle
	 0
	 Back / Return
	 Red / Netflix / Search
	 Green / APP / Repeat
	 Yellow / YouTube / Repeat
	 Blue / Prime Video / Random
	 Text / Goto
	 Up
	 Left
	 OK
	 Right
	 Down
	 Sleep / Timer
	 Picture / Format
	 Vol+
	 CH+ / Page+



