
























































| Original   | Substitut   | Original  | Substitut   |
|--|---|---|---|
|  Open / Close |  Eject / Surround    |  Subtitle      |  Subtitle / EQ               |
|  TV Input     |  AV / Input / RDS    |  Mute          |  Mute / Dimmer               |
|  TV Power     |  Shift + Power       |  Red           |  Red / Netflix / Search      |
|  Power        |  Power               |  Green         |  Green / APP / Repeat        |
|  1            |  1                   |  Yellow        |  Yellow / YouTube / Repeat   |
|  2            |  2                   |  Blue          |  Blue / Prime Video / Random |
|  3            |  3                   |  Top Menu      |  D.Menu / Top                |
|  Vol+         |  Vol+                |  Up            |  Up                          |
|  4            |  4                   |  Pop Up / Menu |  Menu / Home                 |
|  5            |  5                   |  Left          |  Left                        |
|  6            |  6                   |  OK            |  OK                          |
|  7           |  7                  |  Right        |  Right                      |
|  8          |  8                 |  Return      |  Back / Return             |
|  9          |  9                 |  Down        |  Down                      |
|  Vol-       |  Vol-              |  Options     |  Setup / OPT /             |
|  Audio      |  Audio / Lang I/II |  Home        |  Smart / List              |
|  0          |  0                 |  Home        |  Shift + Menu / Home       |





| Original | Substitut | Original | Substitut             |
|----------|-----------|----------|-----------------------|
|          | <<        |          | << / Preset-          |
|          | Pause     |          | Pause / Step / Freeze |
|          | >>        |          | >>  / Preset+         |
|          | <<        |          | << / Tune-            |
|          | Play      |          | Play / Slow           |
|          | >>        |          | >> / Tune+            |
|          | Display   |          | Display / Media       |
|          | Stop      |          | Stop / Hold           |
|          | SEN       |          | Info / Angle          |
|          |           |          |                       |
|          |           |          |                       |
|          |           |          |                       |
|          |           |          |                       |
|          |           |          |                       |
|          |           |          |                       |
|          |           |          |                       |
|          |           |          |                       |
|          |           |          |                       |
|          |           |          |                       |

