













































































































































































| Original | Substitut | Original | Substitut |
|--|---|--|--|
|  Standby |  Power |  Program |  TV/Radio / |
|  Open/close |  Eject / Surround |  Mute |  Mute / Dimmer |
|  1 |  1 |  N/P |  AV / Input / RDS |
|  2 |  2 |  Time |  Sleep / Timer |
|  3 |  3 |  OSD |  Display / Media |
|  Subtitle |  Subtitle / EQ |  Setup |  Setup / OPT / |
|  4 |  4 |  Up |  Up |
|  5 |  5 |  Title |  Sound / Title |
|  6 |  6 |  Left |  Left |
|  Angle |  Shift + Info / Angle |  Enter |  OK |
|  7 |  7 |  Right |  Right |
|  8 |  8 |  Menu |  Menu / Home |
|  9 |  9 |  Down |  Down |
|  Language |  Audio / Lang I/II |  Return |  Back / Return |
|  0 |  0 |  USB/Card |  Smart / List |
|  +10 |  Guide / EPG / -/- |  Stop |  Stop / Hold |
|  Video |  Shift + 4 |  Play |  Play / Slow |

| Original | Substitut | Original | Substitut |
|--|---|--|--|
|  Standby |  Power |  Program |  TV/Radio / |
|  Open/close |  Eject / Surround |  Mute |  Mute / Dimmer |
|  1 |  1 |  N/P |  AV / Input / RDS |
|  2 |  2 |  Time |  Sleep / Timer |
|  3 |  3 |  OSD |  Display / Media |
|  Subtitle |  Subtitle / EQ |  Setup |  Setup / OPT / |
|  4 |  4 |  Up |  Up |
|  5 |  5 |  Title |  Sound / Title |
|  6 |  6 |  Left |  Left |
|  Angle |  Shift + Info / Angle |  Enter |  OK |
|  7 |  7 |  Right |  Right |
|  8 |  8 |  Menu |  Menu / Home |
|  9 |  9 |  Down |  Down |
|  Language |  Audio / Lang I/II |  Return |  Back / Return |
|  0 |  0 |  USB/Card |  Smart / List |
|  +10 |  Guide / EPG / -/- |  Stop |  Stop / Hold |
|  Video |  Shift + 4 |  Play |  Play / Slow |





| Original | Substitut | Original | Substitut |
|---|-----------|---|---------------------------|
|  | Pause |  | Pause / Step / Freeze |
|  | << |  | << / Tune- |
|  | >> |  | >> / Tune+ |
|  | I<< |  | I<< / Preset- |
|  | >>I |  | >>I / Preset+ |
|  | A-B |  | Yellow / YouTube / Repeat |
|  | Repeat |  | Green / APP / Repeat |
|  | L/R |  | Red / Netflix / Search |
|  | Slow |  | Shift + Play / |
|  | Vol+ |  | Vol+ |
|  | Echo+ |  | CH+ / Page+ |
|  | Mic Vol+ |  | Shift + CH+ / |
|  | Mic |  | Info / Angle |
|  | Vol- |  | Vol- |
|  | Echo- |  | CH- / Page- |
|  | Mic Vol- |  | Shift + CH- / |
|  | Zoom |  | Zoom / Size |

| Original | Substitut |
|----------|-----------|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

