




Original	Substitut	Original	Substitut
 Standby	 Power	 Loudness	 Sound / Title
 Mute	 Mute / Dimmer	 Memory	 Picture / Format
 Search	 Red / Netflix / Search	 Function	 OK
 CD/USB	 Eject / Surround	 1	 1
 Source	 AV / Input / RDS	 2	 2
 Repeat	 Green / APP / Repeat	 3	 3
 Intro	 Shift + OK	 4	 4
 Random	 Blue / Prime Video / Random	 5	 5
 Stop	 Stop / Hold	 6	 6
 CH+	 CH+ / Page+	 7	 7
 >>I	 >>I / Preset+	 8	 8
 CH-	 CH- / Page-	 9	 9
 I<<	 I<< / Preset-	 0	 0
 <</FF-	 << / Tune-	 10+	 Guide / EPG / -/-
 >>/FF+	 >> / Tune+	 Prog	 TV/Radio /
 Play/Pause	 Play / Slow	 Vol-	 Vol-
 DSP	 D.Menu / Top	 Vol+	 Vol+

Menu

<https://mandos-a-distancia.es/ca/Nevir/1065517-79618-comandament-de-substitucio-per-Nevir-Nevir012.html>

