



































Original	Substitut
 Power	 Power
 Vol+	 Vol+
 Vol-	 Vol-
 Mute	 Mute / Dimmer
 Return	 Back / Return
 PR+	 CH+ / Page+
 >>	 >>  / Preset+
  <<	  << / Preset-
 PR-	 CH- / Page-
 Exit	 Exit / Cancel / Clear
 Menu	 Menu / Home
 Up	 Up
 Down	 Down
 Right/Zoom+	 Right
 Left/Zoom-	 Left
 OK	 OK
 Red	 Red / Netflix / Search


Original	Substitut
 Sound	 Sound / Title
 Green	 Green / APP / Repeat
 List	 Shift +  Smart / List
 Yellow	 Yellow / YouTube / Repeat
 Info	 Info / Angle
 Mosaic	 Smart / List
 Blue	 Blue / Prime Video / Random
 Violet	 Display / Media
 Text	 Text / Goto
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8















	Original	Substitut		Original	Substitut
		9		9	9
		0 / - / -		0	0
		AV		AV / Input / RDS	
		PIP		Zoom / Size	
		<< / Pat-Mix		<< / Tune-	
		Play / ?		Play / Slow	
		>>		>> / Tune+	
		Rec/100		Rec / Rec Mode	
		Stop		Stop / Hold	
		Pause / ---		Pause / Step / Freeze	
		Swap PIP		Setup / OPT /	
		Size PIP		Picture / Format	
		Position PIP		TV/Radio /	






Original	Substitut
	 Power
	 Vol+
	 Vol-
	 Mute / Dimmer
	 Back / Return
	 CH+ / Page+
	 >>  / Preset+
	 CH- / Page-
	  << / Preset-
	 Exit / Cancel / Clear
	 Menu / Home
	 Up
	 Down
	 Right
	 Left
	 OK
	 Red / Netflix / Search

Original	Substitut
	 Sound / Title
	 Green / APP / Repeat
	 Shift + Smart / List
	 Info / Angle
	 Yellow / YouTube / Repeat
	 Smart / List
	 Blue / Prime Video / Random
	 Display / Media
	 Text / Goto
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8








































Original	Substitut
 9	 9
 0/-/-	 0
 AV	 AV / Input / RDS
 PIP	 Zoom / Size
 <</Pat-Mix	 << / Tune-
 Play/?	 Play / Slow
 >>	 >> / Tune+
 Rec/100	 Rec / Rec Mode
 Stop	 Stop / Hold
 Pause/----	 Pause / Step / Freeze
 Swap PIP	 Setup / OPT /
 Size PIP	 Picture / Format
 Position PIP	 TV/Radio /

Original	Substitut






Original	Substitut
	 Power
	 Vol+
	 Vol-
	 Mute / Dimmer
	 Back / Return
	 CH+ / Page+
	 >>  / Preset+
	  << / Preset-
	 CH- / Page-
	 Exit / Cancel / Clear
	 Menu / Home
	 Up
	 Down
	 Right
	 Left
	 OK
	 Red / Netflix / Search

Original	Substitut
	 Sound / Title
	 Shift + Smart / List
	 Green / APP / Repeat
	 Info / Angle
	 Yellow / YouTube / Repeat
	 Blue / Prime Video / Random
	 Smart / List
	 Display / Media
	 Text / Goto
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8





Original	Substitut	Original	Substitut
9	9		
0/-/-	0		
AV	AV / Input / RDS		
PIP	Zoom / Size		
<</Pat-Mix	<< / Tune-		
Play/?	Play / Slow		
>>	>> / Tune+		
Rec/100	Rec / Rec Mode		
Stop	Stop / Hold		
Pause/----	Pause / Step / Freeze		
Size PIP	Picture / Format		
Position PIP	TV/Radio /		

