
































































Original		Substitut		Original		Substitut	
	Power		Power		Yellow		Yellow
	Play		Play		Blue		Blue
	Pause		Pause		CH+		Ch +
	<<		<<		CH-		Ch -
	>>		>>		Source		AV
	I<<		I<<		Vol+		Vol +
	>>I		>>I		Vol-		Vol -
	Stop		Stop		Menu		Menu
	TV/TXT		Text		Rec		Rec
	Cancel		Eject		Up		Up
	Reveal		D. Menu		Down		Down
	Hold		Media		Right		Right
	Size		3D		Left		Left
	Subpage		Shift + Subt		OK		Ok
	Index		List		DVB		Smart
	Red		Red		Exit		Exit
	Green		Green		1		1





Original	Substitut
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
-/--	SHIFT + -/-- GUIDE Shift + Guide
↺	RETURN BACK Back
PICTURE	SHIFT + PICTURE FORMAT Shift + Format
SOUND	SHIFT + SOUND DUAL Shift + Dual
NICAM/A2	SETTINGS OPT Options
MUTE	MUTE Mute
SLEEP	PROG SLEEP Sleep
TV/RADIO	SEARCH TV/R TV/R

Original	Substitut
FAV	FAV
FAV+	FAV+
FAV-	FAV-
SUBTITLE	AD SUBT Subt
PIC FORMAT	PICTURE FORMAT Format
TEXT	SHIFT + REPEAT TEXT Shift + Text
DISPLAY	DISPLAY INFO Info
LANGUAGE	SOUND DUAL Dual
EPG	-/-- GUIDE Guide

