

COBY
COMBI
LEDTV 1926 H

Mandis Shop S.L.
Sant Cugat del Vallès - Barcelona
info@mandis.es

Layout Keys	Direct	Shift	Layout Keys	Direct	Shift
	POWER		P/Ch +	CH+	FAV+ / REPEAT
MUTE	MUTE		P/Ch -	CH-	FAV- / A-B
1 <small>..?</small>	1		VOL +	VOL+	
2 <small>ABC</small>	2		VOL -	VOL-	
3 <small>DEF</small>	3			UP	
4 <small>GHI</small>	4			DOWN	
5 <small>JKL</small>	5		OK	OK	
6 <small>MNO</small>	6			LEFT	
7 <small>PQRS</small>	7			RIGHT	
8 <small>TUV</small>	8		MENU	M / MENU	
9 <small>WXYZ</small>	9		EXIT RETURN	EXIT	
0/10	0		TOP MENU	S. MODE	I-II
GUIDE	MEDIA		PICT TITLE	P. MODE	
FAV	FAV		EPG	AUTO / HOLD	SKIP PREV
AUTO/TRK	SLEEP			FREEZE	SKIP NEXT
SUBT	SUBTITLE / STEP			ASPECT	STOP
AV Dvd/Tv	SOURCE		ZOOM	??	
INFO	INFO / SLOW			INDEX / PVR LIST	PLAY / PAUSE
TEXT	TEXT	??	RED	RED	REC / REVEAL
TV	DTV / RADIO		GREEN	GREEN	REW
BACK	S. PAGE		YELLOW	YELLOW	PLAY / PAUSE
			BLUE	BLUE	FWD