

VESTEL
TV
RC2600



Mandis Shop S.L.
Sant Cugat del Vallès (Barcelona)
info@mandis.es

Layout Keys	Direct	Shift	Layout Keys	Direct	Shift
POWER	Power	Sleep	V	Down	
MUTE	Mute		EXIT		
1	1		BACK	MTS	
2	2		VOL+	Vol+	
3	3		VOL-	Vol-	
4	4		INFO	Index	
5	5		FAV(LIST)	Reveal	
6	6		CH+	PR+	
7	7		CH-	PR-	
8	8		TEXT	Text	
9	9		<P>	Hold/Still	
0	0		...	ARC	Subpage
VOL	APC		TV/RADIO	Mix	
MENU	Menu	Update/Position	OPT+	Review	
PLAY			SOURCE	TV/AV	
PAUSE			V-FORMAT	Size	
STOP			WIDF	PIP	Multi PIP
RECORD					
<<					
>>					
<<					
>>					
RED	Red/PIP CH-				
GREEN	Green/PIP CH+				
YELLOW	Yellow/Swap				
BLUE	Blue/Input				
MEDIA	ASC	Multimedia			
PG(GUIDE)	Mode				
OK	OK				
^	Up				
<	Left				
>	Right				