
































































Original	Replacement
 Power	 Power
 Source	 SRC
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 TTX/MIX	 TEXT
 PRE-CH	 P/C / FAV
 Vol+	 VOL +
 Vol-	 VOL -
 Mute	 MUTE

Original	Replacement
 P+	 CH +
 P-	 CH -
 CH List	 TV/R
 Content	 Shift + VOD
 Menu	 MENU
 Guide	 -/-- / EPG
 Tools	 OPT+
 Info	 INFO
 Return	 BACK
 Exit	 EXIT
 Up	 UP
 Down	 DOWN
 Right	 RIGHT
 Left	 LEFT
 Enter	 OK
 Red	 Red (A)
 Green	 Green (B)





Original	Replacement	Original	Replacement
 Yellow	 Yellow (C)		
 Blue	 Blue (D)		
 Media. P	 MEDIA		
 Internet/@TV	 VOD		
 Dual I-II	 Audio		
 AD	 WIDE		
 P.Size	 V-FOR		
 Subt.	 Subt.		
 <<	 Rewind		
 Pause	 Pause		
 >>	 Fast Forward		
 Rec	 Rec		
 Play	 Play		
 Stop	 Stop		

