







































































Original	Replacement	Original	Replacement
 Power	 Power	 0	 0
 Setup	 Setup / OPT /	 Movie	 Display / Media
 DTV	 D.Menu / Top	 Music	 Smart / List
 1	 1	 Photo	 Picture / Format
 2	 2	 Vol-	 Vol-
 3	 3	 Vol+	 Vol+
 HDMI/AV	 AV / Input / RDS	 Up	 Up
 4	 4	 Left	 Left
 5	 5	 Enter	 OK
 6	 6	 Right	 Right
 Disc	 Shift + 3	 Exit	 Exit / Cancel / Clear
 7	 7	 Down	 Down
 8	 8	 Home	 Menu / Home
 9	 9	 Edit	 Back / Return
 Rec	 Rec / Rec Mode	 Copy	 Shift + Smart / List
 EPG	 Guide / EPG / -/--	 Repeat	 Green / APP / Repeat
 TTX	 Text / Goto	 <<	 << / Tune-





Original	Replacement	Original	Replacement
Play/Pause	Play / Slow		
I<<	I<< / Preset-		
>>	>> / Tune+		
Stop	Stop / Hold		
>>	>> / Preset+		
Audio	Audio / Lang I/II		
Sub-T	Subtitle / EQ		
FAV	Fav / Marker / PC		
Info	Info / Angle		
Mute	Mute / Dimmer		
DVD	Shift + 2		
Timer	Sleep / Timer		
T/R	Zoom / Size		

