





































Original	Replacement
 Power	 Power
 Screen	 Picture / Format
 Lang	 Audio / Lang I/II
 Subttl	 Subtitle / EQ
 PIP	 Display / Media
 EPG	 Guide / EPG / -/--
 FAV	 Fav / Marker / PC
 Presets	 Smart / List
 Sleep	 Sleep / Timer
 Red/Up	 Red / Netflix / Search
 Green/Down	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 1	 1
 2	 2
 3	 3
 4	 4

Original	Replacement
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 [≡]/Text	 Text / Goto
 0	 0
 Recall	 Back / Return
 Vol-	 Vol-
 Vol+	 Vol+
 P-	 CH- / Page-
 P+	 CH+ / Page+
 Mute	 Mute / Dimmer
 Source	 AV / Input / RDS
 Up	 Up
 Left	 Left
 OK	 OK



