




Original	Replacement	Original	Replacement
 Power	 Power	 Menu	 Menu
 Mute	 Mute	 EPG	 Guide
 1	 1	 Exit	 Exit
 2	 2	 Up	 Up
 3	 3	 Down	 Down
 4	 4	 Right	 Right
 5	 5	 Left	 Left
 6	 6	 OK	 Ok
 7	 7	 CH+	 Ch +
 8	 8	 CH-	 Ch -
 9	 9	 Vol+	 Vol +
 0	 0	 Vol-	 Vol -
 FAV	 +  Shift + Pre Ch	 Red	 Red
 Recall	 +  Pre Ch	 Green	 Green
 Game	 Media	 Yellow	 Yellow
 Auto	 Smart	 Blue	 Blue
 Info	 Info	 Zoom	 Eject





	Original	Replacement		Original	Replacement
	Lan/Audio	 Dual			
	Play	 Play			
	Pause	 Pause			
	<<	 <<			
	>>	 >>			
	Text	 Text			
	Tv/Radio	 TV/R			
	Subtitle	 Subt			

