















































Original	Replacement
 Power	 Power
 Open/Close	 Eject
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 10+	 Guide
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Title/TTX	 Text

Original	Replacement
 Menu	 Menu
 Prog/EPG	 Sleep
 Display	 Info
 Goto	 Pre Ch
 PBC	 Options
 Setup	 D. Menu
 Return	 Back
 Source	 AV
 Tv/Radio	 TV/R
 Play	 Play
 Stop	 Stop
 Pause	 Pause
 <</Rev	 <<
 >>/Fwd	 >>
 <</Prev	 <<
 >> /Next	 >>
 Up	 Up





Original	Replacement	Original	Replacement
 Down	 Down		
 Right/Fav+	 Right		
 Left/Fav-	 Left		
 Enter	 Ok		
 3D	 3D		
 Subtitle	 Subt		
 Zoom	 Shift + Eject		
 Mode	 Smart		
 Digest	 Blue		
 Language	 Dual		
 L/R	 Media		
 P/N	 Red		
 Repeat	 Shift + Text		
 A-B	 Yellow		
 Angle	 Green		
 Slow	 Format		

