





































| Original   | Replacement  |
|--|--|
|  Source |  Shift + AV / Input / RDS     |
|  Power  |  Power                        |
|  List   |  Smart / List                 |
|  TV     |  Shift + 1                    |
|  DVD    |  Shift + 2                    |
|  1      |  1                            |
|  2      |  2                            |
|  3      |  3                            |
|  4      |  4                            |
|  5     |  5                           |
|  6    |  6                          |
|  7    |  7                          |
|  8    |  8                          |
|  9    |  9                          |
|  AV   |  AV / Input / RDS           |
|  0/-- |  Shift + Guide / EPG / -/-- |
|  FAV  |  Fav / Marker / PC          |

| Original   | Replacement  |
|--|--|
|  Exit         |  Exit / Cancel / Clear    |
|  Menu         |  Menu / Home              |
|  Up           |  Up                       |
|  Left/Zoom-   |  Left                     |
|  OK           |  OK                       |
|  Right/Zoom+  |  Right                    |
|  Down         |  Down                     |
|  Guide        |  Guide / EPG / -/--       |
|  Return       |  Back / Return            |
|  Info        |  Info / Angle            |
|  Vol+       |  Vol+                   |
|  Presets    |  Setup / OPT /          |
|  PR+        |  CH+ / Page+            |
|  Vol-       |  Vol-                   |
|  PR-        |  CH- / Page-            |
|  Mute       |  Mute / Dimmer          |
|  Red/O Lang |  Red / Netflix / Search |

































































| Original |                 | Replacement |                             | Original | Replacement |
|----------|-----------------|-------------|-----------------------------|----------|-------------|
|          | Red(O) Lang     |             | Audio / Lang I/II           |          |             |
|          | Green/Subtitles |             | Subtitle / EQ               |          |             |
|          | Green/Subtitles |             | Green / APP / Repeat        |          |             |
|          | Yellow          |             | Yellow / YouTube / Repeat   |          |             |
|          | Blue            |             | Blue / Prime Video / Random |          |             |
|          | Violet/Text     |             | Text / Goto                 |          |             |
|          | Stop Text       |             | Shift + Stop /              |          |             |
|          | ??? Text        |             | Sleep / Timer               |          |             |
|          | Zoom Text       |             | Zoom / Size                 |          |             |
|          | Media/Digital   |             | Display / Media             |          |             |
|          | <<              |             | << / Tune-                  |          |             |
|          | Play            |             | Play / Slow                 |          |             |
|          | >>              |             | >> / Tune+                  |          |             |
|          | T-Link          |             | D.Menu / Top                |          |             |
|          | Rec             |             | Rec / Rec Mode              |          |             |
|          | Stop            |             | Stop / Hold                 |          |             |
|          | Pause           |             | Pause / Step / Freeze       |          |             |





| Original  | Replacement  |
|---|--|
|    |  Power                        |
|    |  Smart / List                 |
|    |  Shift + 1                    |
|    |  Shift + 2                    |
|    |  1                            |
|    |  2                            |
|    |  3                            |
|    |  4                            |
|    |  5                            |
|    |  6                            |
|  |  7                          |
|  |  8                          |
|  |  9                          |
|  |  AV / Input / RDS           |
|  |  Shift + Guide / EPG / -/-- |
|  |  Exit / Cancel / Clear      |
|  |  Menu / Home                |

| Original  | Replacement  |
|---|--|
|    |  Up                       |
|    |  Left                     |
|    |  OK                       |
|    |  Right                    |
|    |  Down                     |
|    |  Guide / EPG / -/--       |
|    |  Back / Return            |
|    |  Info / Angle             |
|    |  Vol+                     |
|    |  Setup / OPT /            |
|  |  CH+ / Page+            |
|  |  Vol-                   |
|  |  CH- / Page-            |
|  |  Mute / Dimmer          |
|  |  Audio / Lang I/II      |
|  |  Red / Netflix / Search |
|  |  Subtitle / EQ          |





| Original        | Replacement                 | Original | Replacement |
|-----------------|-----------------------------|----------|-------------|
| Green/Subtitles | Green / APP / Repeat        |          |             |
| Yellow          | Yellow / YouTube / Repeat   |          |             |
| Blue            | Blue / Prime Video / Random |          |             |
| Violet/Text     | Text / Goto                 |          |             |
| <<              | << / Tune-                  |          |             |
| Play            | Play / Slow                 |          |             |
| >>              | >> / Tune+                  |          |             |
| Rec             | Rec / Rec Mode              |          |             |
| Stop            | Stop / Hold                 |          |             |
| Pause           | Pause / Step / Freeze       |          |             |
|                 |                             |          |             |
|                 |                             |          |             |
|                 |                             |          |             |
|                 |                             |          |             |
|                 |                             |          |             |
|                 |                             |          |             |
|                 |                             |          |             |
|                 |                             |          |             |
|                 |                             |          |             |
|                 |                             |          |             |





| Original       | Replacement               |
|----------------|---------------------------|
| Source / Eject | Eject / Surround          |
| Power          | Power                     |
| List           | Smart / List              |
| TV             | Shift + 1                 |
| DVD            | Shift + 2                 |
| 1              | 1                         |
| 2              | 2                         |
| 3              | 3                         |
| 4              | 4                         |
| 5              | 5                         |
| 6              | 6                         |
| 7              | 7                         |
| 8              | 8                         |
| 9              | 9                         |
| AV             | AV / Input / RDS          |
| 0 / --         | Shift + Guide / EPG / -/- |
| FAV            | Fav / Marker / PC         |

| Original  | Replacement                |
|-----------|----------------------------|
| Exit      | Exit / Cancel / Clear      |
| Menu      | Menu / Home                |
| Up        | Up                         |
| Left      | Left                       |
| OK        | OK                         |
| Right     | Right                      |
| Down      | Down                       |
| Guide     | Guide / EPG / -/-          |
| Return    | Back / Return              |
| Info      | Info / Angle               |
| Vol +     | Vol+                       |
| PR +      | CH+ / Page+                |
| Vol -     | Vol-                       |
| PR -      | CH- / Page-                |
| Mute      | Mute / Dimmer              |
| Red / A-B | Shift + Yellow / YouTube / |
| Red / A-B | Red / Netflix / Search     |





| Original          | Replacement                 | Original | Replacement |
|-------------------|-----------------------------|----------|-------------|
| Green / Subtitles | Green / APP / Repeat        |          |             |
| Green / Subtitles | Subtitle / EQ               |          |             |
| Yellow / Size     | Yellow / YouTube / Repeat   |          |             |
| Yellow / Size     | Zoom / Size                 |          |             |
| Blue / Lang       | Blue / Prime Video / Random |          |             |
| Blue / Lang       | Audio / Lang I/II           |          |             |
| Purple / Text     | Text / Goto                 |          |             |
| Text Stop         | Shift + Stop /              |          |             |
| Text ???          | Sleep / Timer               |          |             |
| Text Zoom         | Shift + Zoom /              |          |             |
| <<                | << / Tune-                  |          |             |
| Play              | Play / Slow                 |          |             |
| >>                | >> / Tune+                  |          |             |
| Stop              | Stop / Hold                 |          |             |
| Pause             | Pause / Step / Freeze       |          |             |
|                   |                             |          |             |
|                   |                             |          |             |

