







































Original	Replacement
 Power	 Power
 Mute	 Mute
 Zoom	 Eject
 FAV	 Pre Ch
 FAV+	 Vol +
 FAV-	 Vol -
 Info	 Info
 P/N	 Smart
 Page+	 Ch +
 Page-	 Ch -
 Menu	 Menu
 Exit	 Exit
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok

Original	Replacement
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Subtitle	 Subt
 Text	 Text
 [+]	 Options
 Tv/Radio	 TV/R
 Recall	 Back
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8





Original		Replacement		Original		Replacement	
	9		9				
	0		0				
	Audio		Dual				
	EPG		Guide				
	<<		<<				
	Play		Play				
	>>		>>				
	Stop		Stop				
	Pause		Pause				
	I<<		I<<				
	>>I		>>I				
	Rec		Rec				
	Rec List		List				

