








































































































Original	Replacement	Original	Replacement
 Power	 Power	 Menu	 Menu
 Mute	 Mute	 Exit	 Exit
 1	 1	 Source	 AV
 2	 2	 Display	 Info
 3	 3	 Up	 Up
 4	 4	 Down	 Down
 5	 5	 Right	 Right
 6	 6	 Left	 Left
 7	 7	 Enter	 Ok
 8	 8	 Lang/Audio	 Dual
 9	 9	 Reclist	 List
 0	 0	 Rec	 Rec
 DTV/ATV	 Smart	 FAV/List	 Pre Ch
 Return	 Back	 Freeze	 Media
 P.Mode	 Shift + Format	 Vol+	 Vol +
 S.Mode	 Shift + Dual	 Vol-	 Vol -
 Sleep	 Sleep	 CH+	 Ch +

Original	Replacement	Original	Replacement
 Menu	 Menu	 Exit	 Exit
 Source	 AV	 Display	 Info
 Up	 Up	 Down	 Down
 Right	 Right	 Left	 Left
 Enter	 Ok	 Lang/Audio	 Dual
 Reclist	 List	 Rec	 Rec
 FAV/List	 Pre Ch	 Freeze	 Media
 Vol+	 Vol +	 Vol-	 Vol -
 CH+	 Ch +		



