



Original		Replacement		Original		Replacement	
	Power		Power		Angle		Red
	Goto		Pre Ch		Audio		Dual
	Source		AV		PBC		Green
	Mute		Mute		Title		Back
	1		1		Slow		Media
	2		2		Setup		Options
	3		3		Zoom		Eject
	4		4		Menu		Menu
	5		5		Up		Up
	6		6		Down		Down
	7		7		Right		Right
	8		8		Left		Left
	9		9		Enter		Ok
	0		0		Repeat		Text
	10+		Guide		AB		TV/R
	Step		Format		Program		Sleep
	Subtitle		Subt		Display		Info



