







































































Original	Replacement	Original	Replacement
 Power	 Power	 4	 4
 FAV	 Pre Ch	 5	 5
 Tv/Radio	 TV/R	 6	 6
 Audio	 Dual	 7	 7
 Format	 Format	 8	 8
 Source	 AV	 9	 9
 Play	 Play	 0	 0
 REC	 Rec	 MENU	 Menu
 Stop/Rec List	 Stop	 EXIT	 Exit
 >>/[≡?]	 >>	 Vol+	 Vol +
 <</[≡◇]	 <<	 Vol-	 Vol -
  <</[≡+]	  <<	 Mute	 Mute
 Pause/[≡i]	 Pause	 CH+	 Ch +
 >> /O	 >>	 CH-	 Ch -
 1	 1	 Guide	 Guide
 2	 2	 ?	 Info
 3	 3	 Back	 Back





Original	Replacement	Original	Replacement
 Up	 Up		
 Down	 Down		
 Right	 Right		
 Left	 Left		
 OK	 Ok		
 Text	 Text		
 Subt	 Subt		
 Red	 Red		
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		

