
















































Original		Replacement		Original		Replacement	
	Power		Power		3D		3D
	Back		Back		123/Input		Media
	Home		Smart		Mute		Mute
	TV		TV/R		Mouse Up		>>
	Micro		Dual		Mouse Down		<<
	Up		Up		OK		Ok
	Down		Down				
	Left		Left				
	Right		Right				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	Vol+		Vol +				
	Vol-		Vol -				
	P+		Ch +				
	P-		Ch -				

