







































































Original	Replacement	Original	Replacement
 Power	 Power	 Blue/[ ]	 Blue
 Vol+	 Vol +	 Info	 Info
 Vol-	 Vol -	 Text	 Text
 PR+	 Ch +	 1	 1
 PR-	 Ch -	 2	 2
 Mute	 Mute	 3	 3
 Menu	 Menu	 4	 4
 Exit	 Exit	 5	 5
 Back	 Back	 6	 6
 OK	 Ok	 7	 7
 Up	 Up	 8	 8
 Down	 Down	 9	 9
 Right/Zoom+	 Right	 0	 0
 Left/Zoom-	 Left	 AV	 AV
 Red/[o]	 Red	 SP/LP	 Media
 Green/Timer/List	 Green	 Play	 Play
 Yellow	 Yellow	 >>	 >>





Original	Replacement	Original	Replacement
	<<		<<
	Stop		Stop
	Pause		Pause
	Rec		Rec
	Mark		3D
	0000		Guide

Original	Replacement











Original	Replacement	Original	Replacement
Power	Power	Blue/[ ]	Blue
Vol+	Vol +	Info	Info
Vol-	Vol -	Text	Text
Mute	Mute	Play	Play
PR+	Ch +	Stop	Stop
PR-	Ch -	Rec	Rec
Exit	Exit	Pause	Pause
Menu	Menu	>>	>>
Back	Back	<<	<<
Up	Up	1	1
Down	Down	2	2
Right/Zoom+	Right	3	3
Left/Zoom-	Left	4	4
OK	Ok	5	5
Red/[o]	Red	6	6
Green/Timer/List	Green	7	7
Yellow	Yellow	8	8






























































Original		Replacement		Original		Replacement	
	9		9				
	AV		AV				
	SP/LP		Media				












Original	Replacement	Original	Replacement
	 Power		 Blue
	 Vol +		 Info
	 Vol -		 Text
	 Mute		 1
	 Ch +		 2
	 Ch -		 3
	 Menu		 4
	 Exit		 5
	 Back		 6
	 Up		 7
	 Down		 8
	 Right		 9
	 Left		 0
	 Ok		 AV
	 Red		 Media
	 Green		 Play
	 Yellow		 Stop





Original		Replacement		Original		Replacement	
	>>		>>				
	<<		<<				
	Rec		Rec				
	Pause		Pause				
	Mark		3D				
	0000		Guide				

