







































































Original		Replacement		Original		Replacement	
	Power		Power		HDD Browser		Smart
	Tv/HDD		TV/R		Disc Menu		D. Menu
	Tuner		Subt		Up		Up
	CAM		Media		Down		Down
	Guide		Guide		Right		Right
	1		1		Left		Left
	2		2		OK		Ok
	3		3		CH+		Ch +
	4		4		CH-		Ch -
	5		5		Stop		Stop
	6		6		Pause		Pause
	7		7		Play		Play
	8		8		I<</Day-		I<<
	9		9		>>I/Day+		>>I
	0		0		Rec		Rec
	T/C		Pre Ch		Back/Jump		<<
	Back		Back		FWD Jump		>>



