



	Original	Replacement		Original	Replacement
	Power		Power		Exit
	Mute		Mute		Up
	1		1		Down
	2		2		Right
	3		3		Left
	4		4		Ok
	5		5		Vol +
	6		6		Vol -
	7		7		Sound
	8		8		Pic
	9		9		Ch +
	0		0		Ch -
	Audio		Dual		Sleep
	Recall		Back		Aspect
	Tv Menu		Menu		Freeze
	Source		AV		Tv/Radio
	ChList		List		Text





	Original	Replacement		Original	Replacement
	Epg	 GUIDE			I<<
	Fav	 PRE-CH			>>I
	Info	 INFO			Play
	Red	 A			Pause
	Green	 B			Stop
	Yellow	 C			Rec/Rep
	Blue	 D			
	Reveal	 MEDIA			
	Hold	 D.MENU			
	Index	 SHIFT +  INFO	Shift + Info		
	Subpage	 SHIFT +  AV	Shift + AV		
	List	 SMART			
	Mix	 OPT			
	Subtitle	 SUBT			
	Size	 3D			
	<<		<<		
	>>		>>		

