































































































Original	Replacement	Original	Replacement
 Standby	 Power	 HDD/Browser	 Media
 CAM	 Pre Ch	 Guide/TV	 Guide
 TV/HDD	 TV/R	 Up	 Up
 Return	 Back	 Down	 Down
 Edit	 Format	 Right	 Right
 Timer	 AV	 Left	 Left
 Select	 Options	 OK	 Ok
 Y/Tuner	 Text	 CH+	 Ch +
 Menu/System	 D. Menu	 CH-	 Ch -
 Menu/Disc	 Menu	 Stop	 Stop
 Info	 Info	 Pause	 Pause
 Vol+ Tv	 Vol +	 Play	 Play
 Vol- Tv	 Vol -	 I<<	 I<<
 Red	 Red	 Rec/OTR	 Rec
 Green	 Green	 >>I	 >>I
 Yellow	 Yellow	 Jump Back	 <<
 Blue	 Blue	 Jump FWD	 >>





Original	Replacement	Original	Replacement
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	T/C		Eject
	Disc Manager		List

