




































Original	Replacement	Original	Replacement
Power		Power	 Subtitle / EQ
OK		Settings	 Setup / OPT /
Up		>>	 >>I / Preset+
Down		>>	 >> / Tune+
Right		Play	 Play / Slow
Left		AD / PIP	 Sound / Title
Back		<<	 I<< / Preset-
Vol +		<<	 << / Tune-
Vol -		Rec	 Rec / Rec Mode
Home / Smart		Pause	 Pause / Step / Freeze
3D	 +  Shift + 3	Text	 Text / Goto
Mute		FAV	 Fav / Marker / PC
P +		Exit	 Exit / Cancel / Clear
P -		Input	 AV / Input / RDS
Ratio		Blue	 Blue / Prime Video / Random
List		Yellow	 Yellow / YouTube / Repeat
Q.Menu		Stop / Live TV	 Stop / Hold

Menu



Original	Replacement	Original	Replacement
AV Mode	 +  Shift + AV / Input / RDS	5	 5
Green	 Green / APP / Repeat	Q.View	 +  Shift + Display / Media
Red	 Red / Netflix / Search	4	 4
0	 0	Live Zoom	 Zoom / Size
AD	 Audio / Lang I/II	3	 3
TV / PC	 +  Shift + Fav / Marker / PC	2	 2
Search	 +  Shift + Red / Netflix /	1	 1
App	 +  Shift + Green / APP /	T.Opt	 +  Shift + Setup / OPT / Tools
TV / Radio	 TV/Radio /	Energy Saving	 Eject / Surround
Guide	 Guide / EPG / -/--	My APPS	 +  Shift + Smart / List
Info	 Info / Angle		
Recent	 Sleep / Timer		
9	 9		
8	 8		
7	 7		
Live Menu	 Display / Media		
6	 6		

