


































| Original | Replacement | Original | Replacement |
|----------------|---|-----------------------------|---|
| Power |  | Power |  |
| OK |  | OK |  |
| Up |  | Up |  |
| Down |  | Down |  |
| Right |  | Right |  |
| Left |  | Left |  |
| Back |  | Back / Return |  |
| Vol + |  | Vol+ |  |
| Vol - |  | Vol- |  |
| Home / Smart |  | Menu / Home |  |
| 3D |  | Shift + 3 |  |
| Mute |  | Mute / Dimmer |  |
| P + |  | CH+ / Page+ |  |
| P - |  | CH- / Page- |  |
| Ratio |  | Picture / Format |  |
| List |  | Smart / List |  |
| Q.Menu |  | D.Menu / Top |  |
| Subtitle |  | Subtitle / EQ |  |
| Settings |  | Setup / OPT / |  |
| >> |  | >> / Preset+ |  |
| >> |  | >> / Tune+ |  |
| Play |  | Play / Slow |  |
| AD / PIP |  | Sound / Title |  |
| << |  | I<< / Preset- |  |
| << |  | << / Tune- |  |
| Rec |  | Rec / Rec Mode |  |
| Pause |  | Pause / Step / Freeze |  |
| Text |  | Text / Goto |  |
| FAV |  | Fav / Marker / PC |  |
| Exit |  | Exit / Cancel / Clear |  |
| Input |  | AV / Input / RDS |  |
| Blue |  | Blue / Prime Video / Random |  |
| Yellow |  | Yellow / YouTube / Repeat |  |
| Stop / Live TV |  | Stop / Hold |  |



| Original | Replacement | Original | Replacement |
|------------|---|---------------|---|
| AV Mode |  +  Shift + AV / Input / RDS | 5 |  5 |
| Green |  Green / APP / Repeat | Q.View |  +  Shift + Display / Media |
| Red |  Red / Netflix / Search | 4 |  4 |
| 0 |  0 | Live Zoom |  Zoom / Size |
| AD |  Audio / Lang I/II | 3 |  3 |
| TV / PC |  +  Shift + Fav / Marker / PC | 2 |  2 |
| Search |  +  Shift + Red / Netflix / | 1 |  1 |
| App |  +  Shift + Green / APP / | T.Opt |  +  Shift + Setup / OPT / Tools |
| TV / Radio |  TV/Radio / | Energy Saving |  Eject / Surround |
| Guide |  Guide / EPG / -/-- | My APPS |  +  Shift + Smart / List |
| Info |  Info / Angle | | |
| Recent |  Sleep / Timer | | |
| 9 |  9 | | |
| 8 |  8 | | |
| 7 |  7 | | |
| Live Menu |  Display / Media | | |
| 6 |  6 | | |

