


























































Original	Replacement
 Open/Close	 Eject / Surround
 Standby	 Power
 Source	 AV / Input / RDS
 Function	 D.Menu / Top
 TFT On/Off	 Exit / Cancel / Clear
 Mute	 Mute / Dimmer
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 +10	 Shift + Guide / EPG / -/-

Original	Replacement
 Setup	 Setup / OPT /
 Return	 Back / Return
 Up	 Up
 Pre/Tun	 Fav / Marker / PC
 Left	 Left
 Enter	 OK
 Right	 Right
 Memo	 Sleep / Timer
 Down	 Down
 Auto	 Rec / Rec Mode
 Pause/Step	 Pause / Step / Freeze
 Play	 Play / Slow
 Stop	 Stop / Hold
 Vol-	 Vol-
 Vol+	 Vol+
 CH-	 CH- / Page-
 CH+	 CH+ / Page+





Original		Replacement	
	I<<		I<< / Preset-
	>>I		>>I / Preset+
	<<		<< / Tune-
	>>		>> / Tune+
	Zoom		Zoom / Size
	Prog		Shift + TV/Radio / Program
	Slow		Shift + Play /
	A-B		Yellow / YouTube / Repeat
	Goto		Text / Goto
	Title		Sound / Title
	Menu		Menu / Home
	Display		Display / Media
	Subtitle		Subtitle / EQ
	N/P		Red / Netflix / Search
	Language		Audio / Lang I/II
	Angle		Info / Angle
	Resume		Smart / List

Original		Replacement	
	Repeat		Green / APP / Repeat
	R/L		Blue / Prime Video / Random
	4:3/16:9		Picture / Format
	EPG		Guide / EPG / -/-
	Tv/Radio		TV/Radio /
	Video		Shift + 4
	EQ		Shift + Subtitle / EQ

