


























































































Original	Replacement
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 SAT	 AV
 FAV	 Pre Ch
 Menu	 Menu
 EPG	 Guide
 Recall	 Back

Original	Replacement
 Exit	 Exit
 Up / CH +	 Up
 Down / CH -	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Vol +	 Vol +
 Vol -	 Vol -
 Page +	 Ch +
 Page -	 Ch -
 Red / TTX	 Red
 Red / TTX	 Text
 Green / SUB.T	 Green
 Green / SUB.T	 Subt
 Yellow / Zoom	 Yellow
 Yellow / Zoom	 Eject
 Blue / MP	 Blue





Original		Replacement		Original	Replacement
	TV / Radio		TV/R		
	Audio		Dual		
	Pause		Pause		
	TV / SAT		Media		
	Rec		Rec		
	P/N		Format		
	Info		Info		
	Pos		Options		
	Play		Play		
	Stop		Stop		
	<<		<<		
	>>		>>		

