















Original	Replacement
 Power	 Power
 Input D/A	 Shift + AV / Input / RDS
 Tv/Radio	 TV/Radio /
 Text	 Text / Goto
 Input Source	 AV / Input / RDS
 Bright+	 Shift + Up
 Bright-	 Shift + Down
 Ratio	 Picture / Format
 I/II	 Audio / Lang I/II
 Simplink	 Display / Media
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 Stop	 Stop / Hold
 Play	 Play / Slow
 Pause	 Pause / Step / Freeze

Original	Replacement
 Rec	 Rec / Rec Mode
 I<<	 I<< / Preset-
 <<	 << / Tune-
 >>	 >> / Tune+
 >>	 >> / Preset+
 Exit	 Exit / Cancel / Clear
 Back	 Back / Return
 Menu	 Menu / Home
 Info	 Info / Angle
 Guide	 Guide / EPG / -/-
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 OK
 Vol+	 Vol+
 Vol-	 Vol-



















Original	Replacement
MUTE	Mute / Dimmer
PR+	CH+ / Page+
PR-	CH- / Page-
FAV	Fav / Marker / PC
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
List	Smart / List
Q.View	D.Menu / Top
Update	Setup / OPT /

Original	Replacement
Index	Zoom / Size
Time	Shift + Sleep / Timer
Sleep	Sleep / Timer
Hold	Shift + Stop /
Reveal	Sound / Title
Subtitle	Subtitle / EQ





Original	Replacement
 Power	 Power
 Stop	 Stop / Hold
 Play	 Play / Slow
 Pause	 Pause / Step / Freeze
 <<<	 <<< / Tune-
 >>>	 >>> / Preset-
 >>>	 >>> / Tune+
 >>>	 >>> / Preset+
 Menu	 Menu / Home
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 OK
 1	 1
 2	 2
 3	 3

Original	Replacement
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0





Original	Replacement
Power	Power
Input Source	AV / Input / RDS
Stop	Stop / Hold
Play	Play / Slow
Pause	Pause / Step / Freeze
Rec	Rec / Rec Mode
<<<	<<< / Tune-
>>>	>>> / Tune+
PR+	CH+ / Page+
PR-	CH- / Page-
1	1
2	2
3	3
4	4
5	5
6	6
7	7

Original	Replacement
8	8
9	9
0	0

