







































































Original		Replacement		Original		Replacement	
	Power		Power		Dimmer		Media
	Open/Close		Eject		*		Pre Ch
	Band		Green		XTS Pro		Guide
	DVD		Blue		Marker		AV
	AUX		Red		Search		TV/R
	USB		Yellow		Audio		Dual
	1		1		Sound		Shift + Dual
	2		2		Subtitle		Subt
	3		3		Virtual		3D
	4		4		Setup		Options
	5		5		Display		Info
	6		6		Menu		Menu
	7		7		Title		List
	8		8		Up/Preset+		Up
	9		9		Down/Preset-		Down
	0		0		Right/Tun+		Right
	Sleep		Sleep		Left/Tun-		Left



