







































































Original	Replacement	Original	Replacement
 Power	 Power	 Vol +	 Vol +
 Energy Saving	 3D	 Vol -	 Vol -
 AV Mode	 Shift + AV	 Fav Mark	 Shift + Pre Ch
 Input	 AV	 Ratio	 Format
 TV / Rad	 TV/R	 Mute	 Mute
 1	 1	 P + / Page +	 Ch +
 2	 2	 P - / Page -	 Ch -
 3	 3	 Menu	 Menu
 4	 4	 Guide	 Guide
 5	 5	 Q.Menu	 D. Menu
 6	 6	 Up	 Up
 7	 7	 Down	 Down
 8	 8	 Right	 Right
 9	 9	 Left	 Left
 0	 0	 OK	 Ok
 List	 List	 Back	 Back
 Q.View	 Pre Ch	 Info	 Info





Original		Replacement		Original	Replacement
	Exit		Exit		
	Red		Red		
	Green		Green		
	Yellow		Yellow		
	Blue		Blue		
	Text		Text		
	T.Opt		Options		
	Subtitle		Subt		
	Stop		Stop		
	Play		Play		
	Pause		Pause		
	<<		<<		
	<<		I<<		
	>>		>>		
	>>		>>I		
	Simplink		Smart		

