



Original	Replacement
Power	Power
VCR/DVD	Media
DVD Timer	Green
VCR Timer	Red
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0/AUX	0
X/Cancel	Exit
Showview/Video Plus+	Guide
Prog/Check	Sleep

Original	Replacement
Display	Info
On Screen/Progressiv	3D
Top	Shift + Menu
Menu	Menu
Set Up	Options
Return	Back
Up	Up
Down	Down
Right	Right
Left	Left
Enter	Ok
I<</Previous	I<<
>>I/Next	>>I
<</Slow-	<<
Play/Select	Play
>>/Slow+	>>
Stop/Clear	Stop









Original	Replacement
Power	Power
VCR/DVD	Media
DVD Timer	Green
VCR Timer	Red
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0/AUX	0
X/Cancel	Exit
Memory/Mark	Smart
Showview/Video Plus+	Guide

Original	Replacement
Prog/Check	Sleep
Display	Info
On Screen/Progressiv	3D
Top	Shift + Menu
Menu	Menu
Set Up	Options
Return	Back
Up	Up
Down	Down
Right	Right
Left	Left
Enter	Ok
I<</Previous	I<<
>>/Next	>>I
<</Slow-	<<
Play Select	Play
>>/Slow+	>>







































Original	Replacement	Original	Replacement
Stop/Clear	Stop		
Pause	Pause		
Rec	Rec		
Remain/Rec	Shift + Rec		
↔	Pre Ch		
→	Blue		
Angle/Live Check	AV		
Subtitle	Subt		
TV/DVD-TV/VCR	TV/R		
Mute/Audio	Mute		
PR+	Ch +		
PR- TV/CBL/DVD	Ch -		
Vol+ Tv	Vol +		
Vol- Tv	Vol -		







Original	Replacement
 Power	 Power
 VCR/DVD	 Media
 DVD Timer	 Green
 VCR Timer	 Red
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0/AUX	 0
 Prog/Check	 Sleep
 Display	 Info
 Top	 Shift + Menu

Original	Replacement
 Menu	 Menu
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Enter	 Ok
 I<</Previous	 I<<
 >>/Next	 >>I
 <</Slow-	 <<
 Play/Select	 Play
 >>/Slow+	 >>
 Stop/Clear	 Stop
 Pause	 Pause
 Rec	 Rec
 Remain/Rec	 Shift + Rec
	 Pre Ch
	 Blue



